

ICOM ID-52A+ Handheld

ADD NEW CHANNEL TO MEMORY

(FOR REPEATER)

1. Choose frequency
PRESS: **VFO/MHZ** | for VFO mode if in MR (memory mode)
PRESS: **QUICK**
Nav. to **BAND SELECT** | Select band
PRESS: **VFO/MHZ** | for 1 MHz-step tuning
Dial to set frequency
2. Choose mode
PRESS: **MODE** | until **FM** appears (upper left)
3. Activate offset and tone modes
PRESS: **QUICK**
Nav. to **DUP** | PRESS **ENTER** | PRESS **LO** (DPAD RT KEY) | ENTER **DUP-** or **DUP+**
PRESS: **QUICK**
Nav. to **TONE** | PRESS: **ENTER** | Nav. to **TONE** | PRESS: **ENTER**
PRESS: **QUICK**
Nav. to **TONE** | PRESS: **ENTER** | Nav. to **TONE** | PRESS: **ENTER**
4. Set offset and repeater access tone
PRESS: **MENU**
PRESS: **SET**
PRESS: **DUP/TONE**
PRESS: **OFFSET FREQ** | Dial to set offset frequency
PRESS: **ENTER**
Nav. to **REPEATER TONE** | PRESS: **ENTER** | Dial to set tone | PRESS: **ENTER**
3. Store Frequency in Memory
PRESS: **MENU**
PRESS and HOLD 1 sec: **MR/MW**
PRESS: **WRITE TO NEW CH**
4. PRESS: **QUICK** | Group Select

EDIT MEMORY CHANNEL

1. PRESS and HOLD: **MR/MW**
2. Select **MANAGE MEMORY**
3. Select **MEMORY CH**
4. Nav. to the channel
5. PRESS: nav. button
6. PRESS: **QUICK**
7. PRESS: **EDIT**
8. Edit fields
9. PRESS: **ENTER**
10. Scroll to bottom, to <<**OVERWRITE**>>
11. PRESS: **YES**

CHANGE POWER: PRESS and HOLD 1 sec: **LO** | Select power level

REVERSE: HOLD: **SQ**