

Explorer QRZ-1

General: Press Menu then use arrows to desired number

Set power level: Menu #9, low 1w, medium 2w, high 5w.

Change bands:

Press Radio, toggle between VFO and Memory mode using the A/B button. In VFO mode use the keypad to enter the repeater's transmit frequency.

Scan Mode:

Menu #14 and select a method:

Carrier: Scanner will halt on a signal as long as station is active

Time: Scanner will halt for some time

Stop: Scanner will halt on a signal and stay. Reinitiate scan when desired

Scan: In VFO: Initiates a scan of the entire operating band starting on current frequency

Set Squelch Sensitivity:

Menu #4. Settings range from 0-9 with a default of 5

Battery Level: Menu #10

Set CTCSS:

Menu #1, select TX=RX or RX, then

Menu #2, select tone, then

Menu to save

PTT to exit

Memory: Press Radio to toggle between VFO and Memory

Channel Storage:

In VFO input frequency the long press Menu. The digits will blink, insert a preset number using the keypad. Press Radio to store.

Reverse Repeater Transmit and Receive Frequencies: Menu #5

Weather Channel: 162.55

Menu Structure:

1. Tone mode
2. Tone select
3. Repeater
4. Squelch
5. Dual Rx
6. Lamp mode
7. Brightness
8. Beep
9. Power
10. Battery
11. VOX
12. VOX level
13. Scan mode
14. Scan, in VFO, initiates a scan of entire operating band
15. TX Block, prevents the radio from transmitting on the same frequency